

Product fiche pursuant to Delegated Regulation (EU) no. 1059/2010

Dishwasher	Answer
Supplier's Name or Trade Mark	Bosch
Model	ActiveWater 60 cm dishwasher
Capacity	12 place settings
Energy efficiency class	A +++
EU Ecolabel (If applicable)	N/A
Annual Energy Consumption - "Energy consumption xx kWh per year, based on 280 standard cleaning cycles using cold water fill and the consumption of the low power modes. Actual energy consumption will depend on how the appliance is used"	Energy consumption in programme Economy 50 °C: 237 kWh per year, based on 280 standard cleaning cycles using cold water fill and the consumption of the low power modes.
Energy Consumption (E t) of the standard cycle	Energy consumption in programme Economy 50 °C: 0.83 kWh
Power consumption in off-mode and left-on mode (P o and P l)	Power consumption off-mode / left-on mode: 0.1 W / 0.1 W
Annual Water Consumption (litres per year). "Water consumption x litres per year, based on 280 standard cleaning cycles. Actual water consumption will depend on how the appliance is used"	Water consumption in programme Economy 50 °C: 2660 litres per year, based on 280 standard cleaning cycles. Actual water consumption will depend on how the appliance is used.
Drying Efficiency Class. "Drying efficiency class X on a scale from G (least efficient) to A (most efficient)"	A
Indication that the "standard programme" relates to the information within the label & fiche and is the most efficient programme in terms of combined energy and water consumption	N/A
Programme time for the standard cleaning cycle (mins)	195 Mins
Duration of the left-on mode (T l) where the dishwasher is fitted with a power management system	0 min
Noise Level (dB(A))	Noise level: 42 dB(A) re 1 Pw
Built-In	Freestanding